

APE POWER UNIT WIRELESS REMOTE CONTROL

# DEEP FOUNDATIONS SOLUTIONS

# **KEY FEATURES**

- Wireless Remote
- **USB Magnetic Charging Dock**
- Range Distance up to 600'
- Rugged Heavy Duty
- Ergonomic Handheld
- Waterproof
- Shockproof
- High-Impact Rated
- **Engine Display**
- Hydraulic Display

### **GOVERNOR**

ENGINE RPM DOWN

Press to decrease RPM by increments of 50 RPM. Hold for Min RPM.

# **DRIVE REVERSE**

Press drive REV button to ENGAGE / DISENGAGE

**ENABLE BUTTON REQUIRED** 

#### **CLAMP OPEN**

Press Clamp Open button to ENGAGE **ENABLE BUTTON REQUIRED** 

#### **DRILL HIGH/LOW**

Press drill High/low to engage **ENABLE BUTTON REQUIRED** 

# ATTENTION

## **ENABLE BUTTON**

Must be depress while pressing any operating buttons: ENGINE START, DRIVE FWD. DRIVE REV, CLAMP OPEN. **CLAMP CLOSE** 



# **VIBRO-DRILL**

#### POWER / EMERGENCY STOP

**WILL SHUT OFF ENGINE, DISENGAGE DRIVE AND ALL** VALVES INSTANTLY.

Control panel will stay on.



#### GOVERNOR

ENGINE RPM UP

Press to increase RPM by increments of 50 RPM. Hold for Max RPM.

#### **DRIVE FORWARD**

Press drive FWD button to ENGAGE / DISENGAGE

**ENABLE BUTTON REQUIRED** 

#### **CLAMP CLOSE**

Press Clamp Close button to ENGAGE **ENABLE BUTTON REQUIRED** 

# **CLAMP PRESSURIZED**

NOTE: When Clamp Line Pressure is ENGAGED, LED will light up blue.

# **ENGINE** START/STOP **START**

Press Engine Start to start. **ENABLE BUTTON IS REQUIRED** 

#### STOP

Press Engine Stop to shut down the engine.



**DRILL HIGH/LOW** 

